

HOW TO CHANGE YOUR RO FILTERS:

Step 1:

Turn off the water supply to drinking water system. This will be either a saddle valve on plumbing system or a shut off valve on the plumbing line.

Step 2:

Turn off the water with the valve at the top of the pressure tank.

Step 3:

Open the faucet to relieve any pressure in plumbing lines.

Step 4:

Turn filters $\frac{1}{2}$ turn counter clockwise, and then pull down.

Step 5:

Insert replacement filters; press filters up and turn $\frac{1}{2}$ turn clockwise.

Note: Filters should be secure; if not repeat step 5.

Step 6:

Slowly turn water back on at inlet supply line and at storage tank.

Step 7:

Check for any leaks around filters.

Note: We suggest emptying tank after first refill because the water may be discolored with activated carbon dust.